







# **MASTER TS-2K LACQUER**

#### PRODUCT DESCRIPTION

Master TS-2K Lacquer is a two-component, water-based floor lacquer that has been specially developed for corridors, sports areas and multi-purpose halls that are exposed to high wear. It excels by providing tough protection, excellent durability and a remarkably high resistance to scuff marks, wear and scratches. This indoor climate labelled lacquer is applied in

a convenient and safe way, and ensures a comfortable indoor climate afterwards.

#### **APPLICATION AREA**

For lacquering new, untreated and newly sanded wood floors in corridors, sports areas etc. Ideal for all types of wood.

### **Product information**

Coverage: 8-10 m²/L
Packaging: 4.5 L + 500 ml Master Classic 2K Hardener
Gloss: Matt/gloss approx. 10, silk-matt/gloss approx. 20 and silkgloss/gloss approx. 40.



#### **Very strong and resistant**

Robust surface with extremely high resistance to black heel marks, scratches, spills and stains. Approved for sports.



## **Drying time**

Between coats: 2-3 hours at 20°C. Light use: 5-6 hours. Fully hard: 5 days



#### Easy to maintain

Can be cleaned and maintained with WOCA Master Cleaner and WOCA Master Care for lacquered surfaces.









## **WORK DESCRIPTION**

#### Preparation

It is important that both wood and lacquer have a temperature of min.  $15^{\circ}$ C (preferably around  $20^{\circ}$ C) and air humidity of approx. 50%. Make sure that the room is well-ventilated for optimal evaporation and drying time.

For the final sanding to bare wood, use grit 100-120 sandpaper or sanding pad. Vacuum thoroughly and wipe the floor down afterwards, using a tightly-wrung water-soaked mop/cloth. Please note: WOCA Intensive Wood Cleaner can help to remove contaminates from fully sanded wooden floors before priming or lacquering. Please allow floor to fully dry overnight. The floor must be completely dry before priming. When priming, use WOCA Master Base Primer for newly sanded wood to reduce side bonding. Alternatively, try WOCA Master Multi Primer for exotic wood species or old wood previously treated with oil or wax.

#### Note

If drying times are not followed, this can result in poor adhesion and reduced resistance. For each coat of lacquer, drying times will be increased. High temperature and low air humidity will reduce drying times. Low temperature and high air humidity will extend drying times.

Maintenance and cleaning Weekly cleaning: Master Cleaner, #684525 Half-yearly care: Master Care, #684125







#### **TREATMENT**

- 1 Apply the primer. When dry, mix WOCA Master Classic 2K Hardener with the lacquer and shake thoroughly before use. Leave the mixture to stand for ten minutes before use, to allow the hardener to activate.
- A coat of Master TS-2K Lacquer should be applied undiluted, using a brush or roller. Leave the surface to dry until next day.
- 3 Sand the surface with grit 120-200 and vacuum clean the surface thoroughly.
- 4 Apply the final coat of Master TS-2K Lacquer with hardener (freshly mixed).

The freshly-lacquered floor is suitable for cautious use after approx. 5-6 hours. Do not place furniture etc. on the floor until at least 24 hours after the final coat of lacquer. The floor will be ready for normal use after approx. 5 days, after which rugs etc. can be placed on the floor.

Water and coloured fluids, such as red wine and coffee, must be wiped off immediately to prevent staining.